



# INSTALLATION INSTRUCTIONS PHONOLOOK SOLUTION DESK

## PHONOLOOK SOLUTION DESK


A- TILT



B- SCREW






C- FASTEN



ALLEN WRENCH 25




1- FASTEN THE "C" BRACKETS TO THE PANEL




2 - VERIFY THAT THE BRACKETS ARE PROPERLY FASTENED TO THE PANEL.

# INSTALLATION INSTRUCTIONS PHONOLOOK SOLUTION DESK


## PHONOLOOK SOLUTION DESK



### 3 - APPLY THE BRACKETS TO THE EDGE OF THE DESK



### 4 - TIGHTEN THE BRACKET



### 5 - VERIFY THE CORRECT PLACEMENT OF THE PANEL