



INSTALLATION INSTRUCTIONS PHONOLOOK ECOMONO

FIXING TO THE WALL WITH SPACED KIT



THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.




THE DISTANCES OF THE HOLES FROM THE EDGE OF THE PANEL ARE SHOWN IN THE FOLLOWING TABLE CHART.

DIMENSIONS	N° FIXING POINTS	DISTANCE X	CABLE DISTANCE FROM THE EDGE	
			DISTANCE Y	DISTANCE C
300 mm x 1200 mm	2	175 mm	150 mm	-
300 mm x 1800 mm	3	175 mm	150 mm	L/2
600 mm x 600 mm	4	175 mm	175 mm	-
600 mm x 1200 mm	4	175 mm	175 mm	-
600 mm x 1800 mm	6	175 mm	175 mm	L/2
1200 mm x 1200 mm	4	175 mm	175 mm	-



POINT
1

DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT
2

CYLINDRICAL CLAMP FIXING

2. INSERT THE EXPANSION DOWEL.
3. FIX THE CYLINDRICAL CLAMP WITH THE SCREW.
4. SCREW THE CYLINDRICAL TUBE TO THE CYLINDRICAL CLAMP.




5. FIX THE CABLE WITH THE SCREW IN THE HOLE OF THE PLATE, PLACING THE SUPPLIED WASHER.




POINT
3

SAFETY CABLE FIXING





LOOP CABLE FIXING




6. FIX THE LOOP CABLE TO THE CYLINDRICAL TUBE.

7. FIX THE MAGNET TO THE CYLINDRICAL TUBE.




PLACEMENT OF THE PANEL



8. PLACE THE PANEL.



FINAL CHECK



9. MAKE SURE THE MAGNET IS ENTIRELY ON THE PLATE.

10. VERIFY THE CORRECT PLACEMENT OF THE PANEL.