



INSTALLATION INSTRUCTION PHONOLOOK ECOMONO
FIXING TO THE WALL WITH SUCTION CUP KIT



THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.




THE FOLLOWING TABLE CHART SHOWS THE DISTANCES BETWEEN THE HOLES AND THE EDGE OF THE PANEL.

DIMENSIONS	N° FIXING POINTS	DISTANCE X	CABLE DISTANCE FROM THE EDGE	
			DISTANCE Y	DISTANCE C
300 mm x 1200 mm	2	175 mm	150 mm	-
300 mm x 1800 mm	3	175 mm	150 mm	L/2
600 mm x 600 mm	4	175 mm	175 mm	-
600 mm x 1200 mm	4	175 mm	175 mm	-
600 mm x 1800 mm	6	175 mm	175 mm	L/2
1200 mm x 1200 mm	4	175 mm	175 mm	-



POINT
1

PREPARATION OF THE SURFACE




1. VERIFY THAT THE SURFACE IS FLAT AND UNIFORM.
2. CLEAN THE SURFACE.



POINT
2

CYLINDRICAL CLAMP AND SUCTION CUP FIXING

3. FIX THE CYLINDRICAL CLAMP WITH THE SCREW.
4. SCREW THE SAFETY NUT TO THE CYLINDRICAL CLAMP.
5. FIX THE SUCTION CUP TO THE CYLINDRICAL CLAMP.



6. DETERMINE THE FASTENING POINTS.
7. PLACE THE PANEL.
8. VERIFY THE CORRECT PLACEMENT OF THE PANEL.



POINT
3

PLACEMENT OF THE PANEL

