





INSTALLATION INSTRUCTIONS PHONOLOOK SOLUTION

ADHERENCE TO THE CEILING




THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.



PHONOLOOK SOLUTION - CEILING INSTALLATION
SOLUTION 3 SAFETY POINTS



PHONOLOOK SOLUTION - CEILING INSTALLATION
SOLUTION 2 SAFETY POINTS



MAGNET DETAIL Ø 25 mm



THE DISTANCES OF THE HOLES FROM THE EDGE OF THE PANEL ARE SHOWN IN THE FOLLOWING TABLE CHART.


DIMENSIONS	N° MAGNETS	N° SAFETY POINTS	MAGNETS DISTANCE FROM THE EDGE(*)		DISTANCE SAFETY POINT	
			DISTANCE Y	DISTANCE X	DISTANCE A	DISTANCE B
300 mm x 1200 mm	4	2	50 mm	30 mm	200 mm	120 mm
300 mm x 1800 mm	4					
600 mm x 600 mm	4					
600 mm x 1200 mm	4					
600 mm x 1800 mm	6	3				
1200 mm x 1200 mm	4	2				
1200 mm x 1800 mm	6	3				

(*) THE MAGNETS MUST BE INSTALLED AT THE BOTTOM OF THE PANEL



POINT
1

DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT
2

MAGNET FIXING




4. INSERT THE EXPANSION DOWELS.
5. CUT THE CHAIN (LENGTH: 150 mm).
6. FIX THE CHAIN WITH THE SCREW, PLACING THE SUPPLIED WASHER.



POINT
3


SAFETY POINT FIXING





POINT
4

APPLICATION OF THE SNAP HOOK




7. INSERT THE SNAP HOOK IN THE HOLE OF THE PLATE.



POINT
5

PLACEMENT OF THE PANEL




8. PLACE THE PANEL



POINT
6

FINAL CHECK



9. MAKE SURE THE MAGNET IS ENTIRELY ON THE PLATE.
10. VERIFY THE CORRECT PLACEMENT OF THE PANEL.