





INSTALLATION INSTRUCTIONS PHONOLOOK ECOMONO SUSPENSION TO THE CEILING




THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.


PHONOLOOK ECOMONO - 6 POINTS




PHONOLOOK ECOMONO - 3 POINTS



CYLINDRICAL CLAMP




CLAMP



SAFETY NUT



CYLINDRICAL CLAMP



STEEL CABLE


THE FOLLOWING TABLE CHART SHOWS THE DISTANCES BETWEEN THE HOLES AND THE EDGE OF THE PANEL.

DIMENSIONS	N° FIXING POINTS	DISTANCE X	CABLE DISTANCE FROM THE EDGE	
			DISTANCE Y	DISTANCE C
300 mm x 1200 mm	2	175 mm	150 mm	-
300 mm x 1800 mm	3	175 mm	150 mm	L/2
600 mm x 600 mm	4	175 mm	175 mm	-
600 mm x 1200 mm	4	175 mm	175 mm	-
600 mm x 1800 mm	6	175 mm	175 mm	L/2
1200 mm x 1200 mm	4	175 mm	175 mm	-



POINT
1

DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT
2

CYLINDRICAL CLAMP FIXING




2. INSERT THE EXPANSION DOWEL.
3. FIX THE CYLINDRICAL CLAMP WITH THE SCREW.



POINT
3

CABLE CLAMP FIXING




4. INSERT THE CABLE INTO THE CABLE CLAMP AND INTO THE CYLINDRICAL CLAMP.
5. TIGHTEN THE CABLE CLAMP COMPLETELY.
6. TIGHTEN FIRMLY THE SAFETY NUT.



POINT
4

APPLICATION OF CLAMP TO THE PANEL




7. FIX THE CLAMP WITH THE SCREW IN THE PANEL.
8. INSERT THE CABLE INTO THE CLAMP AND INTO THE CYLINDRICAL CLAMP, MAKE SURE IT COMES OUT OF THE SIDE HOLE.



POINT
5

PLACEMENT OF THE PANEL




9. SCREW THE CYLINDRICAL CLAMP COMPLETELY.
10. ADJUST THE CABLE LENGTH AS REPORTED IN THE PROJECT.
11. TIGHTEN THE SAFETY NUT.



POINT
6

FINAL CHECK



12. VERIFY THE CLOSURE OF THE SAFETY NUT AND OF THE HOOK.

13. VERIFY THE CORRECT PLACEMENT OF THE PANEL.