



# INSTALLATION INSTRUCTIONS PHONOLOOK SOLUTION

## ADHERENCE TO THE WALL



**THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.**



THE DISTANCES OF THE HOLES FROM THE EDGE OF THE PANEL ARE SHOWN IN THE FOLLOWING TABLE CHART.


DIMENSIONS	N° MAGNETS	N° BRACKETS	MAGNETS DISTANCE FROM THE EDGE (*)		BRACKETS DISTANCE FROM THE EDGE		
			DISTANCE X	DISTANCE Y	DISTANCE A	DISTANCE B	DISTANCE C
300 mm x 1200 mm	2	2	50 mm	30 mm	270 mm	230 mm	50 mm
300 mm x 1800 mm	2						
600 mm x 600 mm	2						
600 mm x 1200 mm	2						
600 mm x 1800 mm	2						
1200 mm x 1200 mm	2						
1200 mm x 1800 mm	2						

(\*) THE MAGNETS MUST BE INSTALLED AT THE BOTTOM OF THE PANEL



POINT  
1

## DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT  
2

## MAGNET FIXING




2. INSERT THE EXPANSION DOWEL.
3. FIX THE MAGNET WITH THE SCREW.



POINT  
3

## BRACKET FIXING




4. INSERT THE EXPANSION DOWELS.
5. FIX THE BRACKET WITH THE SCREW.



POINT  
4

## APPLICATION OF THE SNAP HOOK




6. CUT THE CHAIN (LENGTH: 150 mm).

7. INSERT THE SNAP HOOK IN THE HOLE OF THE PLATE.



POINT  
5

## APPLICATION OF THE SNAP HOOK




8. INSERT THE SECOND SNAP HOOK IN HOLE OF THE BRACKET.



POINT  
6

## PLACEMENT AND FINAL CHECK



9. HANG THE PANEL ON THE BRACKET.

10. VERIFY THE CORRECT PLACEMENT OF THE PANEL.