






# INSTALLATION INSTRUCTIONS PHONOLOOK SOLUTION FIXING TO THE CEILING WITH SPACED KIT




**THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.**


PHONOLOOK SOLUTION - CEILING INSTALLATION  
SOLUTION 3 SAFETY POINTS




PHONOLOOK SOLUTION - WALL INSTALLATION  
SOLUTION 2 SAFETY POINTS




CYLINDRICAL CLAMP



CYLINDRICAL TUBE



MAGNET Ø 25 mm




THE DISTANCES OF THE HOLES FROM THE EDGE OF THE PANEL ARE SHOWN IN THE FOLLOWING TABLE CHART.

DIMENSIONS	N° MAGNETS	N° SAFETY POINTS	MAGNETS DISTANCE FROM THE EDGE		DISTANCE SAFETY POINT	
			DISTANCE Y	DISTANCE X	DISTANCE A	DISTANCE B
300 mm x 1200 mm	4	2	30 mm	50 mm	200 mm	120 mm
300 mm x 1800 mm	4					
600 mm x 600 mm	4					
600 mm x 1200 mm	4					
600 mm x 1800 mm	6					
1200 mm x 1200 mm	4	3	30 mm	50 mm	200 mm	120 mm
1200 mm x 1800 mm	6					
1200 mm x 2400 mm	6	3				



POINT  
1

## DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT  
2

## CYLINDRICAL CLAMP FIXING




2. INSERT THE EXPANSION DOWEL.
3. FIX THE CYLINDRICAL CLAMP WITH THE SCREW.



POINT  
3

## CYLINDRICAL TUBE FIXING




4. FIX THE CYLINDRICAL TUBE TO THE CYLINDRICAL CLAMP.
5. FIX THE MAGNET ON THE CYLINDRICAL TUBE.



POINT  
4

## SAFETY POINT FIXING




6. INSERT THE EXPANSION DOWELS.
7. CUT THE CHAIN (LENGTH: 150 mm).
8. FIX THE CHAIN WITH THE SCREW, PLACING THE SUPPLIED WASHER.



POINT  
5

## APPLICATION OF THE SNAP HOOK




9. INSERT THE SNAP HOOK IN THE HOLE OF THE PLATE.



POINT  
6

## CYLINDRICAL TUBE FIXING



10. MAKE SURE THE MAGNET IS ENTIRELY ON THE PLATE.
11. VERIFY THE CORRECT PLACEMENT OF THE PANEL.