





INSTALLATION INSTRUCTIONS PHONOLOOK SOLUTION

BALL IMPACT KIT




THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.


PHONOLOOK SOLUTION - CEILING INSTALLATION



HOOK WITH SAFETY NUT




CABLE CLAMP



SAFETY NUT



HOOK WITH SAFETY NUT



EYELET



STEEL CABLE




THE DISTANCES OF THE HOLES FROM THE EDGE OF THE PANEL ARE SHOWN IN THE FOLLOWING TABLE CHART.

DIMENSIONS	N° CABLES	N° PLATES	CABLE DISTANCE FROM THE EDGE	
			DISTANCE X	DISTANCE Y
1200 mm x 1200 mm	4	4	50 mm	50 mm



POINT
1

DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT
2

EYELET FIXING



2. FIXING THE EYELET IN THE CEILING.
3. INSERT THE HOOK IN THE EYELET.



POINT
3

CLAMP FIXING




4. INSERT THE STEEL CABLE INTO THE HOOK CLAMP.
5. TIGHTEN THE CABLE CLAMP COMPLETELY.
6. TIGHTEN FIRMLY THE SAFETY NUT.



POINT
4

APPLICATION OF THE HOOK




7. INSERT THE HOOK IN THE HOLE OF THE PLATE.



POINT
5

PLACEMENT OF THE PANEL




8. ADJUST THE CABLE LENGTH AS REPORTED IN THE PROJECT.



POINT
6

FINAL CHECK



9. VERIFY THE CLOSURE OF THE SAFETY NUT AND THE HOOK.
10. VERIFY THE CORRECT PLACEMENT OF THE PANEL.