



INSTALLATION INSTRUCTIONS PHONOLOOK SOLUTION

SUSPENSION TO THE CEILING



THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.




THE DISTANCES OF THE HOLES FROM THE EDGE OF THE PANEL ARE SHOWN IN THE FOLLOWING TABLE CHART.

DIMENSIONS	N° CABLES	N° PLATES	CABLE DISTANCE FROM THE EDGE	
			DISTANCE X	DISTANCE Y
300 mm x 1200 mm	4	4	50 mm	50 mm
300 mm x 1800 mm	4	4		
600 mm x 600 mm	4	4		
600 mm x 1200 mm	4	4		
600 mm x 1800 mm	6	6		
1200 mm x 1200 mm	4	4		
1200 mm x 1800 mm	6	6		



POINT
1

DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT
2

CYLINDRICAL CLAMP FIXING




2. INSERT THE EXPANSION DOWEL.
3. FIX THE CYLINDRICAL CLAMP WITH THE SCREW.



POINT
3

CABLE CLAMP FIXING




4. INSERT THE CABLE INTO THE CABLE CLAMP AND INTO THE CYLINDRICAL CLAMP.
5. TIGHTEN THE CABLE CLAMP COMPLETELY.
6. TIGHTEN FIRMLY THE SAFETY NUT.



POINT
4

APPLICATION OF THE HOOK




7. INSERT THE HOOK IN THE HOLE OF THE PLATE.



POINT
5

PLACEMENT OF THE PANEL




8. ADJUST THE CABLE LENGTH AS REPORTED IN THE PROJECT.



POINT
6

FINAL CHECK



9. VERIFY THE CLOSURE OF THE SAFETY NUT AND THE HOOK.
10. VERIFY THE CORRECT PLACEMENT OF THE PANEL.