





INSTALLATION INSTRUCTIONS PHONOLOOK ECOMONO FIXING TO THE CEILING WITH SPACED KIT




THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.


PHONOLOOK ECOMONO - 6 POINTS




PHONOLOOK ECOMONO - 3 POINTS





CYLINDRICAL CLAMP



CYLINDRICAL TUBE



MAGNET




THE DISTANCES OF THE HOLES FROM THE EDGE OF THE PANEL ARE SHOWN IN THE FOLLOWING TABLE CHART.

DIMENSIONS	N° FIXING POINTS	DISTANCE X	CABLE DISTANCE FROM THE EDGE	
			DISTANCE Y	DISTANCE C
300 mm x 1200 mm	2	175 mm	150 mm	-
300 mm x 1800 mm	3	175 mm	150 mm	L/2
600 mm x 600 mm	4	175 mm	175 mm	-
600 mm x 1200 mm	4	175 mm	175 mm	-
600 mm x 1800 mm	6	175 mm	175 mm	L/2
1200 mm x 1200 mm	4	175 mm	175 mm	-



POINT
1

DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT
2


CYLINDRICAL CLAMP FIXING

2. INSERT THE EXPANSION DOWEL.
3. FIX THE CYLINDRICAL CLAMP WITH THE SCREW.
4. SCREW THE CYLINDRICAL TUBE TO THE CYLINDRICAL CLAMP.



POINT
3

SAFETY CABLE FIXING




5. FIX THE CABLE WITH THE SCREW IN THE HOLE OF THE PLATE, PLACING THE SUPPLIED WASHER.



POINT
4

LOOP CABLE FIXING




6. FIX THE LOOP CABLE TO THE CYLINDRICAL TUBE.

7. FIX THE MAGNET TO THE CYLINDRICAL TUBE.



POINT
5

PLACEMENT OF THE PANEL




8. PLACE THE PANEL.



POINT
6

FINAL CHECK



9. MAKE SURE THE MAGNET IS ENTIRELY ON THE PLATE.

10. VERIFY THE CORRECT PLACEMENT OF THE PANEL.