


INSTALLATION INSTRUCTION PHONOLOOK WALL COVERING PANEL



POINT
1

PREPARATION OF THE SURFACE




1. VERIFY THAT THE SURFACE IS FLAT AND UNIFORM.
2. CLEAN THE SURFACE.



POINT
2

ADHESIVE STRIPS FIXING




3. FIX THE ADHESIVE STRIPS TO THE PANEL.
4. PLACE THE PANEL.



POINT
3

PLACEMENT OF THE PANEL



5. VERIFY THE CORRECT PLACEMENT OF THE PANEL.