





INSTALLATION INSTRUCTIONS PHONOLOOK ECOMONO

ADHERENCE TO THE WALL




THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF SCREW AND DOWELS.



PHONOLOOK ECOMONO - WALL INSTALLATION
SOLUTION 3 SAFETY POINTS



MAGNET DETAIL Ø 25 mm



PHONOLOOK ECOMONO - WALL INSTALLATION
SOLUTION 2 SAFETY POINTS




THE DISTANCES OF THE HOLES FROM THE EDGE OF THE PANEL ARE SHOWN IN THE FOLLOWING TABLE CHART.

DIMENSIONS	N° SAFETY POINTS	MAGNETS DISTANCE FROM THE EDGE (*)		DISTANCE OF THE SAFETY POINT FROM THE EDGE			
		DISTANCE X	DISTANCE Y	DISTANCE A	DISTANCE B	DISTANCE C	SAFETY POINTS
300 mm x 1200 mm	2	175 mm	150 mm	215 mm	150 mm	-	2
300 mm x 1800 mm	3	175 mm	150 mm	215 mm	150 mm	-	2
600 mm x 600 mm	4	175 mm	175 mm	215 mm	230 mm	-	2
600 mm x 1200 mm	4	175 mm	175 mm	215 mm	230 mm	-	2
600 mm x 1800 mm	6	175 mm	175 mm	215 mm	230 mm	350 mm	3
1200 mm x 1200 mm	4	175 mm	175 mm	215 mm	230 mm	-	2



POINT
1

DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT
2

MAGNET FIXING




2. INSERT THE EXPANSION DOWEL.
3. FIX THE MAGNET WITH THE SCREW.



POINT
3

SAFETY CABLE FIXING




4. FIX THE CABLE WITH THE SCREW IN THE HOLE OF THE PLATE, PLACING THE SUPPLIED WASHER.



POINT
4

FIXING THE SAFETY CABLE IN THE WALL




5. INSERT THE EXPANSION DOWEL.
6. FIX THE CHAIN WITH THE SCREW, PLACING THE SUPPLIED WASHER.



POINT
5

PLACEMENT OF THE PANEL




7. PLACE THE PANEL



POINT
6

FINAL CHECK



8. MAKE SURE THE MAGNET IS ENTIRELY ON THE PLATE.
9. VERIFY THE CORRECT PLACEMENT OF THE PANEL.